

# **Network Management Card**

## **User Manual**

# Contents

<b>Contents</b>	<b>2</b>
<b>Chapter 1 Overview</b>	<b>3</b>
1.1 NMC package contents	4
1.2 NMC CD Resources	4
1.3 Features	4
1.4 NMC Applications	5
<b>Chapter 2 NMC parameters setting via serial COM port</b>	<b>6</b>
2.1 Configure NMC via serial COM port	6
<b>Chapter 3 NMC&amp;UPS management via web browser</b>	<b>10</b>
3.1 NMC Parameters setting via web browser	10
3.1.1 <i>NMC System menu</i>	10
3.1.2 <i>Date and Time menu</i>	10
3.1.3 <i>Email Notification menu</i>	11
3.1.4 <i>SNMP TRAP Receivers menu</i>	12
3.1.5 <i>SNMPv1/2 Configuration</i>	13
3.1.6 <i>SNMPv3 User Management</i>	14
3.1.7 <i>Firmware Upload menu</i>	14
3.1.8 <i>File Management menu</i>	14
3.1.9 <i>System Log menu</i>	15
3.1.10 <i>Reboot system menu</i>	15
3.2 UPS monitoring via web browser	16
3.2.1 <i>UPS Status menu</i>	16
3.2.2 <i>UPS Alarm menu</i>	16
3.2.3 <i>UPS Parameters menu</i>	17
3.2.4 <i>UPS Powered Devices Menu</i>	18
3.2.5 <i>UPS Identification menu</i>	18
3.2.6 <i>UPS Log menu</i>	19
3.2.7 <i>Event Log menu</i>	20
3.3 UPS control via web browser	20
3.3.1 <i>UPS Battery Test menu</i>	20
3.3.2 <i>UPS Battery Test Schedule menu</i>	21
3.3.3 <i>UPS Control menu</i>	22
3.3.4 <i>UPS Shutdown Schedule menu</i>	22
3.3.5 <i>UPS Shutdown menu</i>	23
3.3.6 <i>UPS Configuration menu</i>	24
<b>Chapter 4 NMC &amp; UPS management via SNMP</b>	<b>25</b>
<b>Chapter 5 NMC Utility - Find NMC in the LAN</b>	<b>26</b>

## **Chapter 1 Overview**

NMC (Network Management Card) can receive the status information of UPS, and also can send commands to control UPS. User can manage UPS with NMC via web browser or via network management software which supports SNMP protocol.

Once UPS output is abnormal or other events are touched off, NMC will protect server or client operating system being shut down safely by working with system protect software (SPS) that can be installed on various operating system. The conditions include: UPS output abnormal, UPS battery low, UPS overload, over temperature, schedule shutdown, etc. User can set the condition, once the event is touched off, NMC will inform SPS of the event and SPS will shut down operating system safely according to the setting of SPS.

***Note: NMC is short for Network Management Card in the following description.***

## 1.1 NMC package contents

1. NMC with mounting bracket, packaged with ESD bag.
2. RJ45 to DB9 converter cable.
3. Quick Installation Guide.
4. NMC CD-ROM.

## 1.2 NMC CD Resources

NMC CD-ROM contains NMC Utility, Quick Installation Guide, User Manual, MIB files, System Protect Software for various OS, and NMC firmware upgrade SOP.

1. NMC Utility --- for searching NMC in LAN and linking to web of the card
2. Quick Installation Guide --- for describing how to configure NMC
3. User Manual --- for NMC function introduction and settings
4. MIB files --- for SNMP monitoring use
5. System Protect Software --- for protecting server or client operating system shutdown safely
6. NMC firmware upgrade SOP --- for describing how to upgrade NMC firmware

## 1.3 Features

- **UPS management by network connection through RJ45 connector**

User can monitor UPS status and control UPS via web browser on the internet.

- **UPS and NMC configuring via SNMP protocol**

User can configure parameters of NMC and control UPS via SNMP protocol on a network management station.

- **RTC function supporting**

- **Standard MIB (RFC1628.mib) and user-defined MIB (EPPC.mib)**

- **EMP (Environment Monitoring Probe) supporting**

- **SSL supporting**

- **Operating system shutdown safely**

System Protect Software can protect server or client operating system shutdown safely.


- **Redundant UPS input shutdown**

If there is more than one UPS supply power to server, user can configure the redundant UPS input shutdown function of SPS (System Protect System), SPS will shut down server safely when the last one UPS can't supply power.

## 1.4 NMC Applications

NMC is kind of SNMP (Simple Network Management Protocol) manager to communicate UPS via Ethernet, it provides access information and send commands for the UPS. NMC supports two communicating protocols which are SNMP and HTTP for application. Through NMS (Network Management Station) or web browser user can access UPS information via Ethernet directly, meanwhile user can manage both UPS and NMC parameters as well.

NMC provides an application program which named SPS (System Protect Software) for multi-servers shutdown purpose. The program provides shutdown function for different operating systems when shutdown events are appearing on UPS. Shutdown events are configurable by user. The shutdown software will proceed the automatic shutdown orderly to prevent the abnormal shut-off of the clients or servers.




## Chapter 2 NMC parameters setting via serial COM port

There are three methods for NMC parameters setting: setting via serial COM port, setting via telnet program, setting via web browser. It offers basic parameters setting through a serial COM port for NMC configuration such as IP Configuration, Pass Through, and Reset Configuration to default, Restart and Password. In this section, it particularly introduces the parameters setting via serial COM port. It is worth mentioning that the telnet program settings menu is same with the serial port settings.

### 2.1 Configure NMC via serial COM port

1. Prepare a computer (with Microsoft Windows XP or later version)
2. Insert NMC into UPS's intelligent slot exactly.
3. Tighten NMC with screw.
4. Connect the serial port of computer with NMC via RJ45 to DB9 converter cable, the cable is supplied in NMC package.
5. On the computer with Microsoft Windows (XP or later version, supporting Hyper Terminal), select **Hyper Terminal** from **start→all programs**, refer to the following diagram.




6. Input a name and select the connection icon.

## Network Management Card




7. Select the correct connection port.



8. Configure the parameters of the serial port: **9600** bps, **8** bits, **None** parity, **1** stop bit and **None** flow control.


## Network Management Card



9. Please turn on UPS and waiting NMC start successfully, there will be some information shown on the hyper terminal interface. Refer to the following diagram, input NMC password, the default password of NMC is **password**




10. After inputting the NMC password, all main menus will be shown on the hyper terminal interface, refer to the following diagram.



11. Basing on the main menus, please select "1" to configure IP address, gateway, subnet mask and DHCP, refer to the following diagram.

## Network Management Card



12. Basing on the main menus, please select “2” to send command to UPS, the function is just for double checking UPS reply data correctly or not.
13. Basing on the main menu, please select “3” to configure NMC parameters to default value.
14. Basing on the main menus, please select “4” to restart NMC.
15. Basing on the main menus, please select “5” to modify NMC password.
16. Basing on the main menus, please select “0” to exit main menus

## Chapter 3 NMC&UPS management via web browser

In this section, it particularly introduces how to configure NMC, manage UPS and monitor UPS parameters via web browser.

### 3.1 NMC Parameters setting via web browser

*Please Note: Before implementing the NMC setting for all configuring parameters, user has to become NMC administrator first. While configure parameters for NMC via web browser, there will be a pop-up dialog to ask the name and password of NMC administrator. Only NMC password can be changed, regarding to change password by serial COM port, please refer to the item 15 of the section 2.1.*

#### 3.1.1 NMC System menu

NMC system menu can be accessed by **Settings→NMC System**. In this menu it offers configuring for DHCP function, default is enabled; NMC IP address; SNMP version; SMTP function; UPS description; UPS location; NMC web language change function and data log interval. Please refer to the following diagram 3.1.1.

Please Note: NMC must restart via Reboot System menu after changed IP address via web browser to make IP setting active immediately.




Diagram 3.1.1

#### 3.1.2 Date and Time menu

Date and Time menu can be accessed by **Settings→Date and Time**. There are three methods for configuring NMC date and time: configure the

## Network Management Card

date and time of NMC same as user's computer; manually setting the date and time through input the date and time by user self; enter the NTP server address and select a time zone, make the NMC clock synchronized with the NTP server time. Please refer to the following diagram 3.1.2.




Diagram 3.1.2

### 3.1.3 Email Notification menu

Email Notification menu can be accessed by **Settings→Email**

**Notification.** NMC will send an Email to user when UPS event happens.

Email Message Setting, there are columns which Mail Server, User Account, User Password, Sender's Email address, Mail Subject Prefix, Mail Server Port, Mail Daily Report At and Attached File must be input according to what user wants to define.

Recipient List Settings, four Email receiver address can be configured at most; user can input description for each Email address. The functions of Mail Type and Event Level are as following.

Email Type:

- None: It means that NMC won't send any Email to the mail account when event happens on UPS.
- Events: It means that NMC will send an Email when to the mail account when event happens on UPS.
- Daily status: It means that NMC will send UPS daily logs reports to the mail account and the delivery time is configured by "Mail Daily Report At" column. Note: user is able to select History Log, Event Log and System Log report by tick Attached File column.
- Events/Status: It means that NMC will send an event report to the mail account when event happens on UPS and meanwhile NMC will send the daily logs reports as well.

Event Level:

## Network Management Card

- Information: It means that NMC will send an Email to the mail account once event happens on UPS.
- Warning: It means that NMC will send an Email to the mail account once warning event happens on UPS.
- Severe: It means that NMC will send an Email to the mail account once severe event happens on UPS.

Refer to the following diagram 3.1.3.




Diagram 3.1.3

### 3.1.4 SNMP TRAP Receivers menu

SNMP trap receivers menu can be assessed by **UPS Management**→**SNMP TRAP Receivers**. In this menu, the columns NMS IP address, Trap Type, Severity and Description are configured by user's demand. The default of Community Strings column is "public", and it can't change by anyone. Trap type support two trap types which are RFC1628 Trap and EPPC Trap.

#### Severity:

- Information: It means that NMC will send a trap message to the NMS IP address once event happens on UPS.
- Warning: It means that NMC will send a trap message to the NMS IP address once warning event happens on UPS.
- Severe: It means that NMC will send a trap message to the NMS IP address once severe event happens on UPS.

User can input description for each NMS IP address in description column. Refer to the following diagram 3.1.4.

## Network Management Card

Index	NMS IP Address	Community String	Trap Type	Severity	Description
1	172.18.127.127	*****	EPPC Trap	Information	EPPC
2	172.18.127.107	*****	RFC1628 Trap	Information	1628
3		*****	None	Information	
4		*****	None	Information	
5		*****	None	Information	
6		*****	None	Information	
7		*****	None	Information	
8		*****	None	Information	

Diagram 3.1.4

### 3.1.5 SNMPv1/2 Configuration

NMC Support SNMPv1 and SNMPv2 monitor, refer to Diagram 3.1.5.

User can set SNMPv1 and SNMPv2 community strings.

The default public community string is public. And the private community string is private.

SNMPv1/2 Community Strings	
Public Community String	*****
Private Community String	*****

Diagram 3.1.5

### 3.1.6 SNMPv3 User Management

To enhance security users can enable SNMPv3 management mechanism, NMC can add SNMPv3 user through setting user name and validate password.

Enter **Settings**→**NMC System**, select SNMP Support to SNMPv3, the SNMPv3 menu option will appear to the left window, and then select **settings**→**SNMPv3 USM Table** to add SNMPv3 user, refer to Diagram 3.1.6.

User need set SNMPv3 user name, Authentication password, Private password, Security level, Authentication, User status.

Security level can choose no Authentication no Private password, Authentication but no Private, or both Authentication and Private password; Authentication is MD5 encryption mode; User status can choose enable or disable.

User Name	Authentication Password	Private Password	Security Level	Authentication	User Status
			noAuthNoPriv	HMAC-MD5	Disable
			noAuthNoPriv	HMAC-MD5	Disable
			noAuthNoPriv	HMAC-MD5	Disable
			noAuthNoPriv	HMAC-MD5	Disable
			noAuthNoPriv	HMAC-MD5	Disable
			noAuthNoPriv	HMAC-MD5	Disable
			noAuthNoPriv	HMAC-MD5	Disable
			noAuthNoPriv	HMAC-MD5	Disable
			noAuthNoPriv	HMAC-MD5	Disable
			noAuthNoPriv	HMAC-MD5	Disable

Diagram 3.1.6

### 3.1.7 Firmware Upload menu

Firmware upload menu can be accessed by **Settings**→**Firmware Upload**. This menu offers upload NMC firmware via web browser. When user is going to upload NMC firmware, user has to become administrator of NMC first. The default name is “**root**”, and the default password is “**password**” for login as administrator. Regarding upload NMC firmware procedure, please refer to the file **NMC Firmware Upgrade SOP.pdf** for detail information.

### 3.1.8 File Management menu

NMC file management menu can be accessed by **Settings**→**File Management**. The function of this menu is uploading files for the same configuration for different NMC. Only **confsnmp.cfg** (about NMC parameters) and **confups.cfg** (about UPS parameters set by NMC) these two files are available for application. After uploaded files NMC has to reboot immediately

## Network Management Card


to make new configuration active. Regarding to reboot NMC system via web browser, please refer to section 3.1.9 and for reboot NMC system via serial COM port, please refer to item 14 in section 2.1. Furthermore it also can reboot NMC system manually by pull-out and push-in NMC from the Intelligent slot of UPS.

Note: Once .cfg file is deleted, and then reboots NMC system. The configuration of NMC system and UPS will be back to the default setting.

If user would like to save .cfg and .csv file on local computer, it can be achieved by click the file name directly.

### 3.1.9 System Log menu

NMC system log menu can be accessed by **Logs→System Log**. The menu allows user to view NMC system logs. Please refer to diagram 3.1.8.



NETWORK MANAGEMENT CARD FOR UPS		
ON-LINE		Location: Office
15/08/2012 16:25:18		
UPS Monitoring	10/08/2012	15:23:18
UPS Status	10/08/2012	15:46:05
UPS Alarm	10/08/2012	15:46:05
UPS Parameters	10/08/2012	15:47:00
UPS Powered Devices	10/08/2012	16:18:07
UPS Identification	10/08/2012	16:18:07
UPS Management	10/08/2012	16:19:03
UPS Battery Test	10/08/2012	16:30:35
UPS Battery Test Schedule	10/08/2012	16:30:35
SNMP TRAP Receivers	10/08/2012	16:31:31
UPS Configuration	10/08/2012	16:43:47
UPS Control	10/08/2012	16:43:47
UPS Shutdown	10/08/2012	16:44:43
Shutdown Schedule	10/08/2012	16:48:24
Settings	10/08/2012	16:49:21
NMC System	13/08/2012	09:32:55
Reboot System	13/08/2012	10:15:37
Date and Time	13/08/2012	10:31:26
SNMPv1/2 Configuration	13/08/2012	13:15:25
Email Notification	13/08/2012	13:21:16
Firmware Upload	13/08/2012	16:15:36
File Management	13/08/2012	16:56:58
Logs	13/08/2012	17:05:04
UPS Log	13/08/2012	17:38:15
Event Log	13/08/2012	17:39:42
System Log		

Diagram 3.1.8

### 3.1.10 Reboot system menu


NMC reboot system menu can be accessed by **Setting→Reboot System**. The menu offers a function for user to reboot NMC system if it is necessary. When user is going to reboot NMC system, user has to become administrator of NMC first. The default name is “**root**” and the default password is “**password**” for login as administrator.

## Network Management Card

### 3.2 UPS monitoring via web browser

#### 3.2.1 UPS Status menu

UPS status menu can be accessed by **UPS Monitoring→UPS Status**. User can view real-time operating status of the UPS from the web page directly. Please refer to diagram 3.2.1.



The screenshot shows a Microsoft Internet Explorer browser window with the following details:

- Address Bar:** http://172.18.127.5/authority\_ok.html
- Title Bar:** Network Management ... x Network Management Card
- Page Content:** NETWORK MANAGEMENT CARD FOR UPS
- UPS Status:** ON-LINE, Location: Office, 15/08/2012 16:25:53
- Left Sidebar (UPS Monitoring):**
  - UPS Status
  - UPS Alarm
  - UPS Parameters
  - UPS Powered Devices
  - UPS Identification
  - UPS Management** (selected)
  - UPS Battery Test
  - UPS Battery Test Schedule
  - SNMP TRAP Receivers
  - UPS Configuration
  - UPS Control
  - UPS Shutdown
  - Shutdown Schedule
  - Settings** (selected)
  - NMC System
  - Reboot System
  - Date and Time
  - SNMPv1/2 Configuration
  - Email Notification
  - Firmware Upload
  - File Management
  - Logs** (selected)
  - UPS Log
  - Event Log
  - System Log
- UPS Monitoring » UPS Status** (Table):

UPS Monitoring » UPS Status	
<b>UPS Status</b>	Line
<b>UPS Temperature</b>	25.8 °C
<b>Input</b>	
Voltage	221.3 V
Frequency	50.0 Hz
<b>Output</b>	
Load(%)	0
Voltage	230.2 V
Frequency	49.9 Hz
<b>Battery</b>	
Status	Battery Normal
Capacity(%)	100
Voltage	51.1 V
Time On Battery	00:00:00

Diagram 3.2.1

#### 3.2.2 UPS Alarm menu

UPS Alarm menu can be accessed by **UPS Monitoring→UPS Alarm**. User can view the current warning of UPS on the interface. Please refer to diagram 3.2.2.

## Network Management Card




Diagram 3.2.2

### 3.2.3 UPS Parameters menu

UPS Parameters menu can be accessed by **UPS Monitoring→UPS Parameters**. User can view the rating parameters of UPS on the interface. Such as rating output voltage, rating output frequency, rating output power, different parameters shown on the interface is depended on different UPS type. Please refer to diagram 3.2.3.




Diagram 3.2.3

## Network Management Card

### 3.2.4 UPS Powered Devices Menu

UPS Powered Devices menu can be accessed by **UPS Monitoring→UPS Powered Devices**. The table shows the amount of computers with SPS (System Protect Software) connected with NMC. Once UPS output is abnormal, NMC will send shutdown command to the computer with SPS, and computer will be shut down safely by SPS.

User can test remote computer with SPS shutdown function by configure test event.

Please refer to diagram 3.2.4.




Diagram 3.2.4

### 3.2.5 UPS Identification menu

UPS Identification menu can be accessed by **UPS Monitoring→UPS Identification**. There will be UPS type, UPS description (refer to section 3.1.1), UPS firmware version, NMC firmware version and MAC address. Please refer to diagram 3.2.5.

## Network Management Card




Diagram 3.2.5

### 3.2.6 UPS Log menu

UPS Log menu can be accessed by **Logs→UPS Log**. There are two hundred latest data logs shown on the interface at most. Please refer to diagram 3.2.6. User can export **upsdata.csv** file to view more data logs from file management interface, please refer to section 3.1.7.

The screenshot shows the 'Logs » UPS Log' section of the Network Management Card interface. The title bar and top status bar are identical to Diagram 3.2.5. The main content area is titled 'NETWORK MANAGEMENT CARD FOR UPS' and shows a table of UPS log data. The table has columns for Date, Time, Input (Voltage, Frequency), Output (Voltage, Frequency, Load (%)), Battery (Capacity (%)), and Time On Battery (min). The data shows 20 entries from 15/08/2012 at various times, with voltages ranging from 219.8 to 230.4 and frequencies from 49.9 to 50.0. The table is scrollable, with a vertical scrollbar on the right.

Date	Time	Input		Output		Battery		Time On Battery (min)
		Voltage	Frequency	Voltage	Frequency	Load (%)	Capacity (%)	
15/08/2012	13:08:36	223.1	49.9	230.4	50.0	0	100	0.0
15/08/2012	13:09:36	223.1	50.0	230.0	49.9	0	100	0.0
15/08/2012	13:10:36	222.0	49.9	230.2	49.9	0	100	0.0
15/08/2012	13:11:36	222.2	49.9	230.2	49.9	0	100	0.0
15/08/2012	13:12:36	222.4	49.9	230.4	49.9	0	100	0.0
15/08/2012	13:13:36	222.2	49.9	230.0	49.9	0	100	0.0
15/08/2012	13:14:36	222.0	49.9	230.0	49.9	0	100	0.0
15/08/2012	13:15:36	221.8	49.9	229.8	49.9	0	100	0.0
15/08/2012	13:16:36	222.2	49.9	229.6	49.9	0	100	0.0
15/08/2012	13:17:36	221.8	49.9	230.2	49.9	0	100	0.0
15/08/2012	13:18:36	222.2	50.0	229.6	49.9	0	100	0.0
15/08/2012	13:19:36	221.3	49.9	230.2	49.9	0	100	0.0
15/08/2012	13:20:36	221.8	50.0	229.6	49.9	0	100	0.0
15/08/2012	13:21:36	221.6	50.0	229.8	50.0	0	100	0.0
15/08/2012	13:22:36	220.7	50.0	229.8	50.0	0	100	0.0
15/08/2012	13:23:36	220.9	50.0	230.0	49.9	0	100	0.0
15/08/2012	13:24:36	220.3	49.9	230.4	49.9	0	100	0.0
15/08/2012	13:25:36	219.8	49.9	230.2	49.9	0	100	0.0
15/08/2012	13:26:36	219.4	49.9	230.0	49.9	0	100	0.0

Diagram 3.2.6

## Network Management Card

### 3.2.7 Event Log menu

Event Log menu can be accessed by **Logs→Event Log**. There are two hundred latest event logs shown on the interface at most. Please refer to diagram 3.2.7. User can export **upsevent.csv** file to view more event logs from file management interface, please refer to section 3.1.7.

Date	Time	Description
29/05/2012	21:43:36	WARNING: Sensor Temperature over high Set point.
29/05/2012	21:44:22	WARNING: Sensor Humidity over high Set point.
29/05/2012	22:03:51	WARNING: Sensor Temperature over high Set point.
29/05/2012	22:04:10	WARNING: Sensor Humidity over high Set point.
31/05/2012	16:04:30	WARNING: Sensor Temperature over high Set point.
31/05/2012	16:05:18	WARNING: Sensor Humidity over high Set point.
05/06/2012	10:47:22	SEVERE: The UPS temperature is too high.
05/06/2012	10:48:21	INFORMATION: The UPS internal temperature return to normal.
06/06/2012	11:01:22	WARNING: Utility power not available.
06/06/2012	11:01:45	INFORMATION: Utility power has restored.
07/06/2012	17:20:42	WARNING: Utility power not available.
07/06/2012	17:20:54	INFORMATION: Utility power has restored.
11/06/2012	06:26:27	WARNING: Utility power not available.
11/06/2012	06:32:34	INFORMATION: The UPS is going to shutdown output.
11/06/2012	06:32:46	WARNING: UPS Output Off.
11/06/2012	06:38:26	SEVERE: The UPS batteries are low and will soon be exhausted.
11/06/2012	06:42:35	INFORMATION: Utility power has restored.
11/06/2012	06:42:37	INFORMATION: The UPS has return from a low battery condition.
11/06/2012	06:42:49	WARNING: The UPS is not going to shutdown output.
11/06/2012	06:43:01	INFORMATION: UPS Output On.
20/06/2012	08:56:07	WARNING: Sensor Temperature over high Set point.
20/06/2012	08:56:07	WARNING: Sensor Humidity over high Set point.
20/06/2012	08:56:36	WARNING: Utility power not available.

Diagram 3.2.7

### 3.3 UPS control via web browser

*Please Note: Before implementing the NMC setting for all configuring parameters, user has to become NMC administrator first. While configure parameters for NMC via web browser, there will be a pop-up dialog to ask the name and password of NMC administrator. Only NMC password can be changed, regarding to change password by serial COM port, please refer to the item 15 of the section 2.1.*

#### 3.3.1 UPS Battery Test menu

UPS Battery Test menu can be accessed by **UPS Management→UPS Battery Test**. UPS battery latest test result and test time are shown on the interface. User can configure “Quick Battery Test”, “Test Until Battery Low”, “Timed Test”, “Cancel Test” and “Clear Test Information”. For some offline UPS, UPS can't support “Test Until Battery Low” and “Timed Test” function, the function is depended on UPS firmware. Please refer to diagram 3.3.1.

## Network Management Card




Diagram 3.3.1

### 3.3.2 UPS Battery Test Schedule menu

UPS Battery Test Schedule menu can be accessed by **UPS Management**→**UPS Battery Test Schedule**.

User can configure schedule test on specific day or weekly day. User can configure “Quick Battery Test”, “Test Until Battery Low” and “Timed Test”. “Battery Test setting Time” is for “Timed Test” function. For some offline UPS, UPS can’t support “Test Until Battery Low” and “Timed Test” function, the function is depended on UPS firmware. Please refer to diagram 3.3.2.




Diagram 3.3.2

## Network Management Card

### 3.3.3 UPS Control menu

UPS Control menu can be accessed by **UPS Management→UPS Control**. User can control UPS output on or off on the interface, please refer to diagram 3.3.3.

When selecting “UPS turn off” item, NMC will send shutdown command to UPS, UPS will shut down output once the delay time has run out. When selecting “UPS Sleep” item, NMC will send shutdown command to UPS, UPS will shut down output once the delay time has run out, and UPS will turn on output once the UPS sleep time has run out. When selecting “UPS Turn on / Cancel shutdown” item, NMC will send cancel shutdown command to UPS, and UPS will turn on output.




Diagram 3.3.3

### 3.3.4 UPS Shutdown Schedule menu

UPS Shutdown Schedule menu can be accessed by **UPS Management→UPS Shutdown Schedule**. User can control UPS output on or off on specific day or on weekly day, please refer to diagram 3.3.4.

## Network Management Card

ON-LINE  
Location: Office  
15/08/2012 16:39:16

UPS Management » UPS Shutdown Schedule			
Weekly			
Shutdown Day	Shutdown Time(hh:mm)	Restart Day	Restart Time(hh:mm)
Monday	10:00	Monday	12:00
Tuesday	10:00	Tuesday	12:00
Wednesday	10:00	Wednesday	12:00
Thursday	10:00	Thursday	12:00
Friday	10:00	Friday	12:00
Saturday	10:00	Saturday	12:00
Sunday	10:00	Sunday	12:00

Specific Day			
Shutdown Day (dd/mm/yyyy)	Shutdown Time (hh:mm)	Restart Day (dd/mm/yyyy)	Restart Time(hh:mm)
15/08/2012	10:00	15/08/2012	12:00
00/00/0000	00:00	00/00/0000	00:00
00/00/0000	00:00	00/00/0000	00:00
00/00/0000	00:00	00/00/0000	00:00
00/00/0000	00:00	00/00/0000	00:00
00/00/0000	00:00	00/00/0000	00:00
00/00/0000	00:00	00/00/0000	00:00
00/00/0000	00:00	00/00/0000	00:00

Diagram 3.3.4

### 3.3.5 UPS Shutdown menu

UPS Shutdown menu can be accessed by **UPS Management**→**UPS**

**Shutdown.** Please refer to diagram 3.3.5. When the selected event happens, NMC will inform the computer installed with SPS (System Protect System) of the event and send the shutdown command to the computer. Here, the computer installed with SPS is the computer shown on UPS powered devices interface (refer to section 3.2.4).

Action type:

- Disable: It means that NMC will do nothing even the event happens on UPS.
- Warning: It means that NMC will inform the computer installed with SPS of the event once the shutdown condition happens.
- Client Shutdown: It means that NMC will inform the computer installed with SPS of the event and send shutdown command to the computer once the shutdown condition happens.
- “UPS Turn Off” means that NMC will inform the computer installed with SPS of the event, send shutdown command to the computer, and also send shutdown command to UPS once the shutdown condition happens, when the delay time has run out, UPS will shut down output. The default value of delay time is 120 seconds.

Warning period means the overall time the warning will be repeatedly once event happens. Warning interval means that NMC will inform the event to the computer installed with SPS every short period once event happens. **N= (Warning period / Warning interval) +1, N means the warning times.**

**Please Note: for client shutdown setting information, please refer to System Protect Software User Manual.pdf**

## Network Management Card

UPS Management » UPS Shutdown			
Event	Actions	Warning Period (Sec)	Warning Interval (Sec)
AC Failed	Client&UPS Shutdown	30	10
Battery Low	Client&UPS Shutdown	30	10
UPS Overload	Client Shutdown	30	10
UPS Over Temperature	Client Shutdown	900	30
Weekly Schedule	Client Shutdown	900	30
Specific Day	Client Shutdown	900	30
EMP Temperature Threshold	Client Shutdown	900	30
EMP Humidity Threshold	Client Shutdown	900	30
EMP Alarm-1	Client Shutdown	900	30
EMP Alarm-2	Client Shutdown	900	30

Cancel UPS Shutdown if events Restored in Shutdown Delay

UPS Shutdown Delay(Sec)

Diagram 3.3.5

### 3.3.6 UPS Configuration menu

UPS Configuration menu can be accessed by **UPS Management**→**UPS Configuration**. User can configure the limited point of UPS overload and over-temperature. For Innova UPS, User can configure UPS buzzer bee. User can configure the limited point of EMP temperature value and humidity value. User can configure the warning setting of EMP: “Normally open”, “Normally closed” or “Not used”. User also can configure UPS last replaced date. Refer to the following diagram 3.3.6.

UPS Management » UPS Configuration			
UPS			
Over Load Set Point(%)	<input type="text" value="90"/>		
Over Temperature Set Point(°C)	<input type="text" value="20"/>		
Buzzer	On <input type="button" value="Save"/>		
EMP			
Sensor	Description	Low Point	High Point
Temperature(°C)	EMP Temperature	<input type="checkbox"/> 15	<input type="checkbox"/> 50
Humidity(%)	EMP Humidity	<input type="checkbox"/> 50	<input type="checkbox"/> 90
Alarm-1	Alarm-1	Not Used <input type="button" value="Save"/>	
Alarm-2	Alarm-2	Not Used <input type="button" value="Save"/>	
UPS Battery			
Last Replace Date(dd/mm/yyyy) <input type="text"/>			
<input type="button" value="Save"/>			

Diagram 3.3.6

## Chapter 4 NMC & UPS management via SNMP


*Please note: if user wants to use NMC via SNMP protocol, please make sure IP address and Gateway of NMC correct. Please refer to section 2.1 or section 3.1.1 for IP address and Gateway settings.*

NMC support SNMP protocol, user can manage NMC and UPS via SNMP NMS (Network Management Station). Load the NMC MIB to the database of SNMP NMS, and user can read or configure the parameters of NMC and UPS. The read community strings is “**public**”, and the write community strings is “**private**.” NMC support two type MIB: one is **RFC1628.mib**, the other is **EPPC.mib**. MIB files can be found in NMC CD-ROM packaged with NMC.

Furthermore, NMC can be monitored by Winpower software via SNMP protocol. For more detail information, please refer to the user manual of Winpower.

## Chapter 5 NMC Utility - Find NMC in the LAN

Via NMC Utility, user can find NMC automatically and quickly in the LAN. User can link to the web of NMC. Please refer to the following diagram.



NMC Utility can be found in NMC CD-ROM packaged with NMC, NMC Utility supports Windows XP / Windows 7.